

Assembly, Operating

& Maintenance Instructions


Attention: Please remove all items from the carton, and verify all pieces before assembly.


BURO MANTRA Chair






Parts List		
KEY	QTY	DESCRIPTION
Α	1	Backrest
В	1	Seat
С	1	5 star Base
D	1	Mechanism
Е	1	Gaslift
F	5	Castors
G	4	Mechanism Screw (M6 25mm)
Н	3	Backrest Screw (M8 20mm)
1	7	Mechanism & Backrest Washers
		(M8 ø17)
J	3	Lock washers (M8ø14°2mm)
K	1	Allen key (M6)







Care & Maintenance

GENERAL CARE

- ${\boldsymbol{\cdot}}$ To maintain the appearance of non-upholstered parts wipe the surface with a clean cloth dampened with a mild detergent solution.
- · Do not remove any parts for separate cleaning.
- $\boldsymbol{\cdot}$ Do not saturate the fabric or interior with water or other cleaning liquids.
- · Do not shampoo clean.
- Do not clean with hot water extraction machine.
- · Do not clean with onsite drycleaning machine.
- · Protect from direct sunlight, heat and weather.

FABRIC UPHOLSTERY CARE

- $\boldsymbol{\cdot}$ Wipe with a clean cloth dampened with a mild upholstery detergent solution.
- · A soft bristle brush may be used to remove ingrained soil.
- Spot clean as above.
- · Treat spills and stains as soon as possible.
- · Persistent stains may require treatment by a
- · May be cleaned with dry powder cleaners.
- · Allow to dry thoroughly before reuse.

Upholstery & Foam Specs*

Flame Resistant: Ca117 Section A Part I & Section D Part II

UPHOLSTERY: FABRIC

Flame Resistance: Ca117 Section E Class I

*This applies only to standard Buro Seating stock. Any customer specified upholstery may not meet these specifications.

Preventative Maintenance & Warning!

- $\boldsymbol{\cdot}$ Use this product only for seating one person at a time.
- Do not use this chair as a step stool/ladder
- · Do not sit on any part of the chair except the seat.
- · Do not use this chair on uneven floor surfaces.
- · Do not interfere with the operating of the gas lift.
- Do not use chair unless all bolts, screws and knobs are tight.
- $\boldsymbol{\cdot}$ At least every six months check all bolts, screws and knobs to ensure they are tight.
- · If any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorised parts.
- Dispose of packaging properly.
- · Plastic bag is not a toy.
- · Do not use plastic bag as a head covering as it may cause suffocation.
- · Failure to follow these warnings could result in serious injury.

